RNG-0802

SET UP INSTRUCTIONS:

- 1. CONNECT BOTTOM AND TOP TUBES FOLLOWING THE LABELS
- 2. CONNECT SIDE TUBES
- 3. CLEAN THE FRAME AND PLACE THEM ON CLEAN PLACE 4. CAREFULLY REMOVE FABRIC COVER FROM BAG
- 5. PLACE COVER AROUND THE BOTTOM OF THE FRAME 6. PULL COVER CAREFULLY UP TO THE TOP
- 7. CLOSE ALL ZIPPERS
- 8. ADJUST FABRIC AROUND THE FRAME
- 9. CONNECT CABLE HARNESS TO THE EYEBOLTS
- 10. COMPLETELY TIGHTEN THREADED CONNECTORS

BREAK DOWN INSTRUCTIONS:

REVERSE SET-UP STEPS TO BREAKDOWN FRAME

FABRIC CARE INSTRUCTIONS:

- 1. UNZIP COVER ZIPPERS
- 2. CAREFULLY REMOVE FABRIC COVER
- 3. CLOSE ALL ZIPPERS
- 4. FOLD OR ROLL NEATLY
- 5. PLACE FABRIC IN COVER BAG

| | QTY | CODE | DESCRIPTION |
|--|-----|-----------------|---|
| | 12 | RNG-08-T1 | TUBE FOR 8' DIAMETER RING HANGING FABRIC STRUCTUR |
| | 6 | SPDR-30-C-2 | 30MM CURVED SPREADER FOR |
| | 9 | TC-30-T | T JUNCTION FOR 30MM TUBING |
| | 3 | TC-30-T-EYEBOLT | T JUNCTION FOR 30MM TUBING |

TOTAL WEIGHT:25.3 (lbs)

GRAPHIC:7.0 (lbs

















