## **PIN-1204**

## SET UP INSTRUCTIONS:

- 1. CONNECT BOTTOM AND TOP TUBES FOLLOWING THE LABELS
- 2. CONNECT SIDE TUBES
- 3. CLEAN THE FRAME AND PLACE THEM ON CLEAN PLACE 4. CAREFULLY REMOVE FABRIC COVER FROM BAG
- 5. PLACE COVER AROUND THE BOTTOM OF THE FRAME
- 6. PULL COVER CAREFULLY UP TO THE TOP
- 7. CLOSE ALL ZIPPERS
- 8. ADJUST FABRIC AROUND THE FRAME
- 9. CONNECT CABLE HARNESS TO THE EYEBOLTS
- 10. COMPLETELY TIGHTEN THREADED CONNECTORS

BREAK DOWN INSTRUCTIONS:

REVERSE SET-UP STEPS TO BREAKDOWN FRAME

FABRIC CARE INSTRUCTIONS:

- 1. UNZIP COVER ZIPPERS
- 2. CAREFULLY REMOVE FABRIC COVER
- 3. CLOSE ALL ZIPPERS
- 4. FOLD OR ROLL NEATLY
- 5. PLACE FABRIC IN COVER BAG

TOTAL WEIGHT: 57.6 (lbs) MAX SIZE:48.6 (in) HARDWARE:33.3 (lbs) GRAPHIC:21.0 (lbs)

QTY	CODE	DESCRIPTION
3	PIN-12-T1-M	TUBE 1 FOR 12' PINWHEEL HANGING FABRIC STRUCTURE (MIRROR)
3	PIN-12-T1	TUBE 1 FOR 12' PINWHEEL HANGING FABRIC STRUCTURE
3	PIN-12-T2-M	TUBE 2 FOR 12' PINWHEEL HANGING FABRIC STRUCTURE (MIRROR)
3	PIN-12-T2	TUBE 2 FOR 12' PINWHEEL HANGING FABRIC STRUCTURE
6	PIN-12-T3	TUBE 3 FOR 12' PINWHEEL HANGING FABRIC STRUCTURE
6	SPDR-30-C-4	30MM CURVED SPREADER FOR 4' STRUCTURES
6	SPDR-30-S4-4	30MM STRAIGHT SPREADER FOR TC-30-T JUNCTIONS OF 4' HIGH 30MM FABRIC STRUCTURE FRAMES
6	TC-30-90	90 DEGREE ELBOW JOINT FOR 30MM TUBING
12	TC-30-T	T JUNCTION FOR 30MM TUBING
3	TC-30-T-OPPOSITE	T JUNCTION FOR 30MM TUBING















