## PIN-1402

SET UP INSTRUCTIONS: 2. CONNECT SIDE TUBES

. CONNECT BOTTOM AND TOP TUBES FOLLOWING THE LABELS

3. CLEAN THE FRAME AND PLACE THEM ON CLEAN PLACE 4. CAREFULLY REMOVE FABRIC COVER FROM BAG
5. PLACE COVER AROUND THE BOTTOM OF THE FRAME
6. PULL COVER CAREFULLY UP TO THE TOP

. CLOSE ALL ZIPPERS

COUSE ALL ZIFFENS
 ADJUST FABRIC AROUND THE FRAME
 CONNECT CABLE HARNESS TO THE EYEBOLTS
 10. COMPLETELY TIGHTEN THREADED CONNECTORS

BREAK DOWN INSTRUCTIONS: REVERSE SET-UP STEPS TO BREAKDOWN FRAME

FABRIC CARE INSTRUCTIONS: 1. UNZIP COVER ZIPPERS 2. CAREFULLY REMOVE FABRIC COVER 3. CLOSE ALL ZIPPERS I. FOLD OR ROLL NEATLY 5. PLACE FABRIC IN COVER BAG

TOTAL WEIGHT: 107.4 (lbs) MAX SIZE:57.0 (in) HARDWARE:86.5 (lbs) GRAPHIC:12.3 (lbs)





















