

# SHD-0805

**SET UP INSTRUCTIONS:**

1. CONNECT BOTTOM AND TOP TUBES FOLLOWING THE LABELS
2. CONNECT SIDE TUBES
3. CLEAN THE FRAME AND PLACE THEM ON CLEAN PLACE
4. CAREFULLY REMOVE FABRIC COVER FROM BAG
5. PLACE COVER AROUND THE BOTTOM OF THE FRAME
6. PULL COVER CAREFULLY UP TO THE TOP
7. CLOSE ALL ZIPPERS
8. ADJUST FABRIC AROUND THE FRAME
9. CONNECT CABLE HARNESS TO THE EYEBOLTS
10. COMPLETELY TIGHTEN THREADED CONNECTORS

**BREAK DOWN INSTRUCTIONS:**  
REVERSE SET-UP STEPS TO BREAKDOWN FRAME

- FABRIC CARE INSTRUCTIONS:**
1. UNZIP COVER ZIPPERS
  2. CAREFULLY REMOVE FABRIC COVER
  3. CLOSE ALL ZIPPERS
  4. FOLD OR ROLL NEATLY
  5. PLACE FABRIC IN COVER BAG

TOTAL WEIGHT: 40.0 (lbs)  
MAX SIZE: 57.5 (in)  
HARDWARE: 20.9 (lbs)  
GRAPHIC: 17.1 (lbs)

| QTY | CODE                 | DESCRIPTION  |
|-----|----------------------|--|
| 6   | SHD-08-T1            | TUBE 1 FOR 12' CONVEX THREE SIDED HANGING FABRIC STRUCTURES      |
| 6   | SHD-08-T1-M          | TUBE 1 FOR 12' CONVEX THREE SIDED HANGING FABRIC STRUCTURES      |
| 3   | SPDR-30-C-5          | 30MM CURVED SPREADER FOR 5' STRUCTURES                           |
| 3   | SPDR-30-R-5          | 30MM STRAIGHT SPREADER FOR CORNERS OF 5' STRUCTURES USING RIVETS |
| 3   | TC-30-A-100°-EYEBOLT | TC-30-A ASSEMBLED at 100° WITH 1/4-20 EYE BOLT                   |
| 3   | TC-30-A-100°         | TC-30-A ASSEMBLED at 100°  |
| 6   | TC-30-T              | T JUNCTION FOR 30MM TUBING                                       |

