

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly



Part Identification - Numbering





MARNING




Spline Connection

Extrusion & Lock Connection







Engaged Lock



DO NOT USE POWER TOOLS




LADDERS OR LIFTS MAY BE REQUIRED




ALL CONNECTIONS MUST BE TIGHTLY SECURED




1) Mounting plate & wing nuts, in packed position.




2) Mounting plate bolt in, packed position.




3) Place mounting plate onto [10] then tighten bolt, part way, allowing some rotation for final positioning.



4) Place fixed counter bolts into mounting plate, then lift counter to re-tighten bolt.





5) Tighten bolt, using hex tool, to secure.



6) Place fixed counter bolts into mounting plate, then secure using wing nuts.


Completed Assembly








Keep mounting plate [11A] and wing nuts attached to counter, when packing.


Keep bolt attached to [10], when packing.


























Monitor Mount Monitor


Mount























Level 4


Order #XXXXX Backwall Assembly

Item	Qty.	Description
1	2	Base Plate
2A,2B	1,1	42" S40 Vertical Extrusion w/ A10 Clamps
3A,3B	1,1	42" S40 Vertical Extrusion w/ A10 Clamps
2C,2D	1,1	42" S40 Vertical Extrusion
3C,3D	1,1	42" S40 Vertical Extrusion
4A,4B	2,2	45" Z45 Horizontal Extrusion
5A,5B	2,2	45" Z45 Horizontal Extrusion
4C,5C	1,1	24" Z45 Horizontal Extrusion
6A,6B	2,2	2.5" S40 Angle-Cut Vertical

Corner Connection with Knob Knob Turn knob clockwise


to tighten lock.

Do not over tighten Knobs



Steps:

- 1) Attach base plates [1] lower verticals [2A] [3A] [2C] and [3C], using bolts.
- 2) Connect verticals [2A to 2B] [2C to 2D], [3A to 3B] and [3C to 3D], using connection bars [B]. See Straight Connection with Knobs detail.
- 3) Connect horizontals [4A to 4B] and [5A to 5B], using connection bars [A]. See Straight Connection with Knobs detail.
- 4) Attach vertical assemblies [2A/2B] [3A/3B] [2C/2D] and [3C/3D] with horizontal assemblies [4A/4B] and [5A/5B]. See Corner Connection with Knob detail.
- 5) Connect extrusions [6A] and [6B] to verticals [2B] [2D] [3B] and [3D]. See 2.5"h Angle-Cut Vertical Attachment detail.





Order #XXXXX Backwall Attachments

Steps:


- 1) Connect lights to top horizontal extrusions. See Light Connection detail.
- 2) Attach assembled Header Frames and affix graphics using Velcro.
- 3) Attach extrusions [10/11] to verticals [2A], [2C], [3C] & [3A]; connect shelf to vertical [2A].
- 4) Attach support legs [10A] to curved extrusions [10].
- 5) Attach flange plates [11A] to top of curved extrusions [10], using bolts.
- 6) Attach counter tops to counter mounting plates [11A]. See Counter Assembly page.
- 7) Attach Wings to A10 clamps. See Clamp Attachment detail.
- 8) Attach Monitor Mounts to verticals [2B] & [3B]. See Monitor Mount Attachment detail.


Item Qty. Description
7/8/9 2/2/2 Header Frame
10 4 30.2" Curved Extrusion


10A 4 Support Leg


11 4 12.184" Horizontal Extrusion

11A 4 Counter Mounting Plate










Qty	Description	


1	8	38" S40 Vertical Extrusion
2,2A	4,4	12" Z45 Horizontal Extrusion
3	4	25" Z45 Horizontal Extrusion

Steps


- 1) Attach horizontals [2] and [2A] between verticals [1], with infills between.
- 2) Attach curved horizontals [3] between front verticals [1], with infill between.
- 3) Place shelf on lip of extrusions [2]. See Extrusion Lip detail.
- 4) Set pedestal top on top of extrusions [2A] and [3].

Repeat steps 1 through 4 for other pedestal assembly.






Top View




* Extrusion Lip

Extrusions [2] have a lip for the shelf to rest upon.







Completed Pedestal Assembly

Qty. 2