



20'


Plan View

10'



SETUP INSTRUCTIONS



 = 1 sq foot

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. **Heat and UV exposure will warp and fade components.**
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection




Engaged Lock



WARNING



DO NOT USE POWER TOOLS




LADDERS OR LIFTS
MAY BE REQUIRED




ALL CONNECTIONS MUST
BE TIGHTLY SECURED




1) Mounting plate & wing nuts, in packed position.




2) Mounting plate bolt in, packed position.




3) Place mounting plate onto [10] then tighten bolt, part way, allowing some rotation for final positioning.



4) Place fixed counter bolts into mounting plate, then lift counter to re-tighten bolt.



5) Tighten bolt, using hex tool, to secure.




6) Place fixed counter bolts into mounting plate, then secure using wing nuts.

Completed Assembly



Counter Attachment




Attach mounting plate to curved extrusion [10], using bolt. Insert fixed bolts, located on underside of counter, into holes of flange plate. Secure with wing nuts.


Keep mounting plate [11A] and wing nuts attached to counter, when packing.

Keep bolt attached to [10], when packing.


Top View of Each Level



Level 1 (Bottom Level)



Level 2



Level 3

Lights


Graphics

Setup Hardware
Base Plates

| Item | Qty. | Description |
|-------|------|--|
| 1 | 2 | Base Plate |
| 2A,2B | 1,1 | 42" S40 Vertical Extrusion w/ A10 Clamps |
| 3A,3B | 1,1 | 42" S40 Vertical Extrusion w/ A10 Clamps |
| 2C,2D | 1,1 | 42" S40 Vertical Extrusion |
| 3C,3D | 1,1 | 42" S40 Vertical Extrusion |
| 4A,4B | 2,2 | 45" Z45 Horizontal Extrusion |
| 5A,5B | 2,2 | 45" Z45 Horizontal Extrusion |
| 4C,5C | 1,1 | 24" Z45 Horizontal Extrusion |
| 6A,6B | 2,2 | 2.5" S40 Angle-Cut Vertical |

Steps:

- 1) Attach base plates [1] lower verticals [2A] [3A] [2C] and [3C], using bolts.
- 2) Connect verticals [2A to 2B] [2C to 2D], [3A to 3B] and [3C to 3D], using connection bars [B]. See [Straight Connection with Knobs](#) detail.
- 3) Connect horizontals [4A to 4B] and [5A to 5B], using connection bars [A]. See [Straight Connection with Knobs](#) detail.
- 4) Attach vertical assemblies [2A/2B] [3A/3B] [2C/2D] and [3C/3D] with horizontal assemblies [4A/4B] and [5A/5B]. See [Corner Connection with Knob](#) detail.
- 5) Connect extrusions [6A] and [6B] to verticals [2B] [2D] [3B] and [3D]. See [2.5" h Angle-Cut Vertical Attachment](#) detail.
- 6) Connect left & right assemblies using horizontals [4C,5C].
- 7) Attach graphic to Velcro on back of assembled Backwall.



When Assembled


★ **Corner Connection with Knob**



Turn knob clockwise to tighten lock.


Do not over tighten Knobs

◆ **Straight Connection with Knobs**




Slide connection bar between extrusions, then turn knobs clockwise to tighten lock.

Do not over tighten Knobs



Steps:

- 1) Connect lights to top horizontal extrusions. See **Light Connection** detail.
- 2) Attach Wings to A10 clamps. See **Clamp Attachment** detail.
- 3) Attach Signs to vertical extrusions [2B] & [3B]. See **Sign Attachment** detail.




Completed Assembly

*** Sign Attachment**

Slide connector into groove of extrusion. Tighten set screws to secure in place. Screw standoff into connector. Place sign between standoff and cap then tighten cap to secure sign.

*** Light Connection**

Slide light onto clip then lock clip into groove of horizontal extrusion.



FRONT VIEW