

Formulate 20' Straight

FMLT-WS20-30MM-01

Formulate® 20' Master Straight backwall incorporates a sleek, straight aluminum frame with a zipper pillowcase fabric graphic to create a sharp, bold backwall that clearly conveys who you are and what you do. Print on just one side or both sides of the graphic to maximize your message and brand exposure.



features and benefits:

- State-of-the-art 30mm aluminum tubing with heavy duty internal spigot connectors
- Easy to store and ship
- Quick to set up
- Kit includes: one frame, one dye-sublimated zipper pillowcase graphic, and one wheeled molded storage case
- Lifetime hardware warranty against manufacturer defects
- Reconfigurable into a 10' version, graphic pillowcase not included.

dimensions:

Hardware	Graphic
<p>Assembled unit: 235" w x 92.49" h x 17.72" d 5969mm(w) x 2349mm(h) x 450mm(d)</p> <p>Approximate weight (includes graphic): 53 lbs / 24 kg</p>	<p>Refer to related graphic template for more information.</p> <p>Visit: www.exhibitors-handbook.com/graphic-templates</p>
Shipping	additional information:
<p>Packing case(s): 1 OCE-2</p> <p>Shipping dimensions: OCE-2: Expandable case length (l) may vary 40" - 66" l x 18" h x 18" d 1016mm-1677mm(l) x 458mm(h) x 458mm(d)</p> <p>Approximate shipping weight (with case): 80 lbs / 37 kg</p>	<p>Graphic material: Dye-sublimated zipper pillowcase fabric</p> <p>Optional accessories: Lumina 8-50 watt halogen lighting, literature pocket, stand-off literature rack, stand-off graphic shelf, graphic header, larger freight cases</p>

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

Included In Your Kit

Tools, Components, & Connectors




ALLEN KEY SET x1



LN114-SCRW x3




TC-30-90T x2



LN114-S2-650 x3

Graphics



FMLT-WS20-30MM-01-G x1

Included In Your Kit



WS10-T6 x2




WS10-T1 x8



WS10-T4 x2




WS10-T5 x2




WS10-T7 x2


Tubes



WV20-01-T1 x1



WV20-01-T2 x1




WS-01-T1 x1



WS10-T2 x12

Exploded View

FMLT-WS-20-30MM-01




Kit Assembly

Step by Step:

Step 1.

Assemble Frame A section A with the snap buttons.


Please reference Connection Method 1 for more details.



Step 2.

Assemble Frame A section B with the snap buttons.


Please reference Connection Method 1 for more details.



Step 3.

Assemble Frame A section C with the snap buttons.


Please reference Connection Method 1 for more details.



Step 4.

Assemble Frame A section D with the snap buttons.

Please reference Connection Method 1 for more details.





Kit Assembly

Step by Step:

Step 5.



With the snap buttons, assemble Frame A sections A through D with the straight tubes in between.

Please reference Connection Method 1 for more details.




Step 6.

Apply the pillowcase graphic A onto Frame A. Zipper up at the bottom of the frame.





Step 7.

Using the provided allen key set, attach the stabilizing base for the left end of Frame A.



Step 8.

Using the provided allen key set, attach the stabilizing base for the middle of Frame A.




Kit Assembly

Step by Step:

Step 9.


Using the provided allen ket set, attach the stabilizing base for the right end of Frame A.

20' backwall setup is complete.



Exploded View

10' Frame Option




Kit Assembly

Step by Step:

Step 1.

Assemble Frame A section A with the snap buttons.


Please reference Connection Method 1 for more details.



Step 2.

Assemble Frame A section B with the snap buttons.


Please reference Connection Method 1 for more details.



Step 3.

Assemble Frame A section C with the snap buttons.



Please reference Connection Method 1 for more details.



Step 4.

With the snap buttons, assemble Frame A sections A through C with the straight tubes in between.

Please reference Connection Method 1 for more details.





Kit Assembly

Step by Step:

Step 5.

Apply the pillowcase graphic onto the frame. Zipper up at the bottom of the frame.

Note: Pillowcase graphic not included.




Step 6.

Using the provided allen key set, attach the stabilizing bases to the left and right ends of the frame as shown in the figure to the right.



Connection Methods

Connection Method 1: SNAP BUTTONS



For spigot connections, compress the unlocked connector and slide into the tube lock access hole. Lock both screws carefully using your allen key tool. Be sure to lock securely, but do not over tighten. For snap button connections, locate the snap button on the connector or swage tube. Locate the hole on the corresponding tube. Press the snap button with your thumb and slide the tube and connector together so that the snap button snaps fully into the lock hole. To disassemble, press the snap button and pull apart.

Connection Method 2: Tube Clamps



Be sure to fully assemble all frames before using clamps. With the clamp unlocked, place one tube of the first frame into the mouth of the clamp. Place the second tube (if applicable) into the second mouth of the clamp. With both frame's tubes in the clamp, be sure to lock securely, but do not overtighten.